

TV setup Codebook Viasat URC176001

Television (TV)

A.R. Systems	0067, 2061, 0382, 0586, 0404, 0485
Accent	0067, 0586
Acec	0042
Acentic	0586
Acer	1369, 1674, 2566, 3660, 3927
Acoustic Solutions	1697, 1757, 1575, 1179, 2309, 1615 1553, 1895, 1067, 2706,
Acronn	2591
Adcom	0655
ADL	1247, 0920, 2225
Admiral	0123, 0393, 0448, 0117, 0193, 0294
Advent	0906, 1724, 1643
Adyson	0098, 0247, 0246
AEG	0636, 1586, 1354, 1067, 1179, 2051 2126, 1697, 1585, 1615, 2269, 2196 2227, 2795, 2505, 3273, 3538, 2271
Agashi	0294, 0246, 0247
AGB	0546
Agef	0117
Agfaphoto	2480, 2269,
Agora	2309, 1615, 2706, 0067
Aiko	0067, 0586, 0401, 0065, 0463, 0102 0391, 0221, 0294, 0247
Aim	0067, 0586, 0304
Airis	1863, 2080, 1561, 2225, 2866, 0586
Aiwa	0731, 1934, 1946, 1938, 1945, 1535
Akai	0391, 1356, 0238, 2227, 0401, 0067 0463, 0221, 0065, 0039, 0102, 0248 0582, 0744, 0193, 0546, 0745, 0632 0586, 0578, 0611, 0510, 0247, 0661 0246, 0294, 0478, 0208, 0407, 0636 0738, 0381, 0616, 1067, 1938, 0503 0678, 0842, 1278, 1965, 2051, 2126 1757, 1338, 1895, 2706, 3097, 1179 1553, 1682, 2862, 3825, 3542
Akiba	0248, 0312, 0485, 0067, 0586, 0324
Akira	2271, 3510, 2363
Akito	0302, 0067, 0586
Akura	1800, 2319, 1717, 0744, 1739, 1697 1067, 0067, 0586, 1675, 0698, 1698 1615, 0389, 0442, 0523, 0039, 0248 0312, 0388, 0294, 2012, 2019, 1877 2013, 1393, 2269, 2171, 2089, 3298
Alba	1067, 1615, 0744, 0067, 3097, 2027 2706, 0698, 0586, 0039, 0448, 0400 0265, 0401, 0385, 0248, 0246, 0617 0277, 0461, 0193, 0517, 0241, 0079 0611, 0066, 1698, 0609, 1934, 1938 0473, 2037, 1965, 2080, 2134, 1895 1179, 3617, 3035, 2591, 3820, 2244 1697
Albiral	0132
Alcyon	0241

AlfaView	1236
Alios	2198
Alkos	0065
Allorgan	0236, 0324, 0247
Allstar	0067, 0586
All-Tel	0895
Ambassador	0207
Amitech	1311, 1812, 0685, 1498, 1879
Amoi	1559, 2372
Amplivision	0247, 0400, 0350
Amstrad	0207, 0039, 1179, 1697, 0546, 0294
	0401, 0248, 0067, 0586, 0463, 0442
	1067, 0678, 0611, 1934, 1354, 2012
	2171
Anam National	0680
Andersson	2706, 1179, 1615, 0067
Anex	0451
Anglo	0039, 0294
Anitech	0039, 0098, 0294, 0067, 0586, 0312
	0132
Ansonic	0400, 1612, 0067, 2829, 0586, 0039
	0698, 0404, 0193, 0322, 0132, 0441
	0289, 0277, 1467, 0042, 0458, 1934
	0134, 1698
AOC	3820, 0655, 1618, 2141, 2244
Apollo	0503
AquaVision	1636
Arc en Ciel	0139, 0226, 0598, 0228
Arcam	0246, 0247
Arçelik	0744, 3463, 2155, 0067, 1338, 2920
arctic	1682
Ardem	0516, 0744, 0663, 0067, 0586, 0745
Arena	0067
Aristona	0586, 0067, 0042, 0043
ART	1067
Art Mito	1615, 2171, 1697
Artax	2199
Arthur Martin	0193, 0267
ASA	0135, 0376, 0100, 0134, 0117, 0193
	0209
Asberg	0067, 0586, 0132
Asora	0039
Asuka	0248, 0247, 0246, 0294, 0312, 1934
Asus	3370
Atec	1636, 1758
Atlantic	0067, 0586, 0246, 0236, 0350, 0289
Atori	0039
Auchan	0193
Audiosonic	0039, 0067, 0404, 0586, 1338, 0139
	0744, 2080, 2089, 0745, 0247, 0400
	0367, 0294, 0248, 0516, 0458, 2013
	2134
Audioton	0247, 0516, 0400, 0294, 0458
Autovox	0117, 2199, 2202, 0236, 0267, 0574
	0379, 0247, 0277, 1179, 1615, 2706
	1697, 2309

Avious	1664					
Avol	2171					
AVP	1934,	1938				
Axxent	0039					
Axxion	2489,	3263				
Azuki	2269					
B&D	1247					
Baier	0906,	1354,	2194,	2195,	2269,	3054
Baird	0139,	0223,	0373,	0220,	0222,	0102
	0103,	0247,	0238,	1934,	1226,	0636
	2242,	3495				
Bang & Olufsen	0595,	0650,	0117,	0305		
Barco	0410,	0582,	0193			
Basic Line	0404,	1179,	0067,	0193,	0698,	0586
	0039,	0248,	0312,	0247,	0485,	0369
	1067,	1698				
Bastide	0247					
Bauer	1645,	2227				
Baur	0176,	0333,	0565,	0225,	0542,	0067
	0586,	0584,	0221,	0391,	0574,	0379
	1535,	1040				
Bazin	0247					
BBK	1771,	1553,	1675,	2271		
Beaumark	0208					
Beko	0744,	2693,	0516,	0065,	0745,	0067
	0448,	0458,	0400,	2309,	0586,	1338
	0636,	0838,	1682,	2230,	2155	
Belson	0728,	0736,	2271,	3273,	2744,	2898
	3326,	1697				
Belstar	1067					
Bennett	0586,	0067				
BenQ	1592,	1745,	2420,	2837,	2865,	2593
	1553,	2244,	3820,	3927		
Bensten	1923,	1356,	1443			
Beon	0067,	0586,	0448			
Beond	1863					
Berthen	0698,	1698,	0586			
Best	0367,	0400,	0451			
Bestar	0067,	0586,	0400,	0404		
Bestar-Daewoo	0404					
Bestwell	1356					
Binatone	0247					
Black Diamond	0644,	1067,	0586,	1179		
Black Panther	0132					
Black Star	0277					
Black Strip	0065					
Blackway	0312,	0248				
Blaupunkt	0584,	1739,	2136,	0225,	0221,	0565
	0230,	0357,	0358,	0478,	0485,	0200
	0066,	2456,	3495			
Blauren	0404,	2305				
Blu:sens	1877,	1879,	2271,	2511,	2744,	3613
Blue Media	1758,	1636				
Blue Sky	0067,	1354,	1067,	0744,	1739,	1179
	0517,	0698,	0745,	0655,	1682,	0654
	1939,	0586,	0248,	0312,	0485,	1964
	1934,	1938,	1698,	0838,	1393,	1344

	1769, 1946, 3818
Blue Star	0312
BlueDiamond	2136, 2456, 3495
Bluetech	2591, 2829
Blush	1805, 1739
Boca	1682
bogo	2591, 3542
Boman	1354
Bondstec	0277
Boots	0302, 0247, 0039
Bork	1393
Bosch	0350, 0357
BPL	0067, 0586, 0312
Brandt	0655, 0139, 0267, 0226, 0228, 0317
	0365, 0598, 0501, 0373, 0590, 2706
	1615, 1697
Brandt Electronique	0317, 0365, 0598
Brimax	1739
Brinkmann	0067, 0586, 0698, 0549, 0448, 0516
	1698
Brionvega	0067, 0586, 0117, 0589
Bristol	2120
Britannia	0246, 0247
Brother	0294
Bruns	0117, 0327, 0458, 0516
BSR	0193, 0324, 0582, 0391
BTC	0248
Bush	1067, 3619, 2706, 1356, 2157, 3035
	2244, 1615, 2155, 1179, 0644, 0690
	0401, 0744, 1586, 0067, 3614, 0698
	1946, 0248, 0193, 1682, 1697, 0379
	0039, 0066, 2271, 0265, 0312, 0302
	0385, 0393, 0404, 0549, 0294, 0391
	0517, 0241, 0238, 0247, 0728, 0736
	0611, 0324, 0582, 0586, 1930, 1934
	1938, 1698, 2012, 1278, 1664, 1712
	1196, 0617, 1717, 1338, 2083, 2090
	2080, 2134, 2013, 2242, 2445, 2269
	3820, 1895, 2918, 1750, 1984, 2703
	0473, 2037, 2089, 2253, 2589, 3617
	3205, 2456,
Cameron	2298, 1553, 0586
Camper	0067, 0586, 0516
Canton	0248
Capsonic	0294
Carad	0640, 0067, 0586, 0698, 1067, 1698
Carena	0485, 0067, 0586
Carrefour	0066, 0100, 0067, 0586
Cascade	0039, 0067, 0586
Casio	0067, 0586, 0193, 0379, 1934
CAT	1712, 2185
Cathay	0067, 1757, 0586
Celcus	1179, 1697, 1615, 0067, 1067, 2706
cello	2171, 1800, 1874, 2276, 2703
Centrum	1067
Centurion	0067, 0586

Century	0117, 0277, 0268
CGE	0104, 0114, 0336, 0448, 0277, 0582 0400, 0193, 1934
Changhong	3464
Chimei	1696
CHL	3097
Cimline	0039, 0265, 0248
Cinetec	2090
Cinex	0678, 1196, 1586, 2012
City	0039
Clarity	1750
Clarivox	0448, 0067, 0586, 0100, 0132, 0327
Clatronic	0067, 2624, 0400, 0401, 0744, 0248 0294, 0586, 0247, 0277, 0039, 0132 0350, 0609, 0678, 1934, 0636, 1354 1179, 1707
Clayton	0415, 1067
CMS	0246, 0247
CMX	2829, 2898, 2862, 3326, 3354, 3357 3186, 3097
Combitech	1938
Compacks	1822
Concorde	0039
Condor	0350, 0067, 0586, 0400, 0246, 0039 0312, 0132, 0277, 0448, 0441, 0193 0294
Conia	1717, 1675
Conrac	0838
Conrad	0067, 0586
Contec	0246, 0039, 0187, 0041, 0066, 0294 0067, 0586
Continental Edison	2271, 0139, 2977, 0267, 0226, 0228 0317, 0517, 0598, 0684
Cosmel	0039, 0367, 0067, 0586
CPTEC	0655, 1393
Crosley	0117, 0277, 0104, 0114, 0582, 0193
Crown	0039, 0742, 2230, 0400, 0516, 0067 0586, 0517, 0744, 0636, 0745, 0451 0448, 0389, 0609, 0238, 0683, 0369 1964, 1067, 1682, 0698, 2051
Crystal	0461
CS Electronics	0444, 0246, 0248, 0277
CTC	0277
CWR-Tech	1585, 1354
Cyberpix	1697
Cybertron	0248
Cytronix	1328
D.Boss	1504, 0067
Daas	0327
Daewoo	0664, 1879, 2128, 2155, 0691, 3222 0529, 2276, 0654, 0404, 1939, 0067 0586, 0039, 0246, 0248, 0247, 0481 1167, 1932, 1938, 0910, 0906, 0895 0728, 0744, 0736, 2305, 2067, 1691 1406, 1825, 3145, 3605, 1110
Daewoo Display	3145
Dainichi	0248, 0246

Daitsu	1297
Dansai	0067, 0586, 0294, 0065, 0246, 0039 0066, 0247, 0238
Dansette	0442
Dantax	0400, 2011, 0516, 1682, 1946, 0744 1067, 0636, 0745, 1938
Datron	0655
Datsura	0238
Dawa	0067, 0586
Daytek	1406, 1661
Daytron	0039, 0404, 0067, 0586
de Graaf	0238, 0074, 0257, 0193, 0578, 0393
Decca	0102, 0079, 0063, 0546, 0067, 0586 0274, 0279, 0302, 0247, 1167, 0651 1934, 1938
Dell	1294
Denko	0294
Denver	0067, 1354, 0586, 2624, 2758, 0636 1219, 2797, 0617, 1879, 2269, 1664 1707, 2171, 2080, 2126, 2051, 1739 2169, 2202, 2227, 2299, 2275, 3611 3614, 3613, 3545, 3097, 1800, 2511 3665, 2480, 3658, 2076, 2795
DER	0223, 0220
Derwent	0231
Desmet	0350, 0067, 0586, 0039, 0117, 0381
DGM	2269, 2089, 2591
Diamant	0067, 0586
DiBoss	0067, 0586, 1504
Dicra	3263, 3354, 3186
Diffé	1994
Digatron	0067, 0586
Digihome	1179, 3205, 1697, 2706
Digiline	0067, 0586, 0135, 0698, 1698
DigiLogic	0067, 0586, 2027
Digimate	0920, 2269
Digital Device	1636
Digitek	1739
Digitrex	3224, 3097
Digivision	0391
DigiX	0910
DiK	0067, 0586
Dikom	2829, 2061, 2591, 2706
diVision	2227
Dixi	0039, 0067, 0586, 0327, 0277, 0247 0117
DMTECH	1994, 1179, 1879, 2480, 2031, 2184 2253, 3510, 3613
DNS	3464
Doma	2724
Domeos	0698, 1698, 0067, 1067
Domland	0424
Doric	0231, 0379
Dream Screen	0684
Dream Vision	1734, 1784
DTS	0039
Dual	0574, 3205, 0379, 0247, 0373, 0549

	1267, 0067, 0586, 0289, 0382, 0424
	0333, 0582, 0193, 1934, 1167, 0661
	1179, 1067, 2271, 1354, 1297, 1697
	1615, 2706, 0744, 2227
Dumont	0117, 0134, 0132, 0247, 0100, 0102
	1934
Dunai	0574, 0193
Dunlop	2829
Durabrand	0067, 1467, 0586, 1682, 1067, 0744
Dux	0067, 0586, 0042
D-Vision	0067, 2012, 2227, 2269, 0586
Dynatron	0067, 0586, 0042
Dyon	2829, 2271, 3495, 3859, 3542,
E.S.C.	0067, 0586, 0247
e:max	1354, 0636, 1561,
Easy Living	1278, 2134, 1739, 1643, 1247, 1338
	1661, 2053, 2035, 2037, 0907, 1196
	1586, 1696, 2489, 1324, 2139
Easy Touch	2089
ECG	3097, 2227, 2269, 2195, 2155, 0067
	1067
Edison-Minerva	0517
Eiki	0765
Elbe	0441, 0465, 0660, 0268, 0640, 0289
	0322, 0400, 0193, 0067, 0586, 0248
	0221, 0247, 0546, 0391, 0582
Elbe-Sharp	0546
Elcit	0117, 0277, 0546, 0132, 0582, 0193
Electrion	1615
Elekta	0039, 1585, 0067, 0586, 0294, 0312
Elenberg	1825, 2298
Elfunk	1238, 1067
ELG	0067, 0586
Elin	0246, 0067, 0586, 0135, 0134, 0578
	0391, 0478, 0379, 0193, 0039
Elite	0248, 0067, 0586, 0350
Elman	0132
Elonex	1806
Elta	0039, 0098, 0294, 0246, 0461
Emco	0277
Emerson	0207, 0744, 0117, 0277, 0067, 0586
	0401, 0100, 0312, 0350, 0391, 0654
	1939, 0516, 0400, 0193, 0351, 1934
	0698, 1698
e-motion	0895, 1739, 2456, 3495, 2136
Emperor	0312
Emprex	1819
Enox.	2703
Epson	1765, 1320
Erae	1401
Erisson	1712
Erres	0067, 0586, 0042
Essentials	2516
Estèle	0582, 0193
Etron	0067, 0586, 0850, 0039, 0193
Eurofeel	0294, 0247, 0684
EuroLine	0067, 2080

Euroman	0246, 0294, 0067, 0586, 0247, 0451 0400
Europa	0067, 0586
Europhon	0067, 0546, 0132, 0193, 0247, 0586 0277, 0582, 0461, 0246
Eurovision	1179
Everline	3542
Evesham	1697, 1278, 1749, 1758, 1636
Evotel	2589, 2591, 3619, 2667
Excel	0067, 0586
Excello	1067
Expert	0236, 0289, 0193
Exquisit	0067, 0586, 0277
F&U	2706
FairTec	1403, 1401
Fenner	0404, 0039, 1697, 1179
Ferguson	0655, 0365, 0222, 1067, 2667, 0103 0317, 0220, 0268, 0223, 0354, 0139 0590, 0373, 2423, 0067, 0586, 0065 0683, 0134, 0138, 0391, 0501, 1934 0578, 0473, 2037, 1946, 1938, 2083 1965, 1984, 2305, 1895, 2456, 3035 3097, 2136, 2706, 2120, 2309
Fidelity	0193, 0542, 0393, 0067, 0586, 0401 0442, 0223, 0246, 0294, 0381, 0462 0574, 1934, 1937, 1938, 0391
Filsai	0247
Finlandia	0238, 0376, 0389, 0578, 0391, 0193 0393, 0102, 0317, 0373, 0075
Finlux	0135, 3205, 0134, 0067, 0586, 0744 0376, 1615, 1697, 0247, 0102, 0582 0193, 0546, 0745, 0100, 0117, 0209 0132, 0441, 0661, 0522, 0510, 1586 0659, 0503, 0448, 0636, 0651, 0838 1278, 1196, 2706, 1179,
Fintec	2012
Firstline	0067, 0586, 0404, 0698, 0744, 0654 0193, 0039, 0324, 0351, 0246, 0415 0277, 0582, 1939, 0132, 0247, 0441 0574, 0379, 0268, 0102, 0265, 0238 0391, 1067, 1698, 0838, 1393, 1179 1401, 1338
Fisher	0134, 0247, 0066, 0238, 0400, 0585 0327, 0075, 0117, 0187, 0391, 0582 0193, 0333, 0574, 0379, 0102
Flint	0067, 0586, 0640, 0102, 0248, 0485 0294
FNR	0132
Foehn & Hirsch	2421, 0208, 1870
Force	1179
Forgestone	0223
Formenti	0193, 0067, 0586, 0516, 0246, 0117 0350, 0582
Formenti-Phoenix	0246, 0350, 0582
Fortress	0123, 0117
Fraba	0067, 0586, 0400
Freesat	1666

Friac	0039, 0067, 0586, 0132, 0451, 0400 0529, 0685, 0640
Frontech	0277, 0294, 0379, 0444, 0393, 0461 0478, 0247, 0039, 0193
Fujimaro	0895
Fujitsu	0713, 0883, 0236, 0102, 0132, 0247 0193, 0039, 0382, 0067, 0586, 0391 0289
Fujitsu General	0039, 0247, 0236, 0193
Fujitsu Siemens	1696, 1328, 1278, 1403, 1179, 0838 2204
Funai	1847, 1424, 1067, 1696, 1625, 0698 0294, 0324, 0333, 0442, 1698, 1535 1934, 0744, 1993, 1682, 3205
Furrion	3357
Future	0067, 0586
Gaba	1067, 0067
Galaxi	0132, 0067, 0586, 0391, 0193
Galaxis	0400, 0448, 0067, 0132, 0586
Galeria	0039
Garza	0586
GBC	0582, 0193, 0039, 0404, 0248, 0393
GE	0373, 0765
Geant Casino	0193
GEC	0193, 0391, 0379, 0067, 0546, 0586 0073, 0102, 0247
Geloso	0277, 0039, 0393, 0582, 0193, 0404
General Electric	0373, 0317
General Technic	0039
Genexxa	0248, 0067, 0586, 0442, 0523, 0193 0039
Gericom	0895, 1636, 1751, 1328, 1236, 3591 1247, 0910, 0838
GoGen	2706, 1179, 1697, 0067, 1067, 3205 1615
Gold	1863, 2053, 1800, 2489
Goldfunk	0698, 1698
Goldhand	0246
Goldline	0367
GoldStar	0067, 0039, 0400, 0320, 0407, 0247 0277, 0246, 0586, 0461, 0193, 0391 0139, 0393, 0636, 0074, 1964, 0744 0745, 0485
Gooding	0517
Goodmans	0664, 1278, 2423, 1697, 1825, 1717 1615, 0654, 1067, 0067, 2013, 0529 0586, 1946, 0744, 0698, 1939, 1179 0404, 0066, 0294, 0102, 0546, 0039 0320, 0209, 0517, 0401, 0373, 0265 0065, 0510, 0590, 0247, 0365, 0248 0481, 1938, 0609, 0660, 0691, 1930 1698, 0910, 1338, 0617, 1406, 1757 1675, 1712, 2088, 1750, 2083, 2076 1749, 2157, 2253, 2445, 2706, 1553 1739, 0838, 1196, 2027, 2195, 2136 2244
Gorenje	0400, 1615, 1697, 0451, 2706

GPM	0248					
Graetz	0391, 1179,	0401, 1615,	0193, 1697	0067,	0369,	0586
Gran Prix	0678,	2366,	3222,	1226,	2227,	2363
Granada	0067,	0586,	0256,	0386,	0389,	0042
	0075,	0102,	0381,	0176,	0138,	0238
	0247,	0066,	0369,	0546,	0231,	0503
	0365,	0590,	0193,	0393,	0255,	0373
	0578					
Grandin	0067,	1682,	0586,	0039,	0193,	0640
	0744,	0745,	0698,	0404,	0350,	0312
	0248,	0485,	0609,	1067,	1698,	0895
	0910,	2155,	2706			
Gronic	0132,	0247,	0193			
Grundig	0225,	1196,	1873,	1253,	1612,	2706
	0473,	0221,	2157,	1717,	0584,	0100
	0565,	1067,	0517,	0067,	2037,	0736
	0267,	0586,	0617,	0039,	0066,	0400
	0770,	1965,	1938,	0660,	1946,	1338
	0208,	1406,	0373,	2011,	1697,	2083
	2269,	2225,	2230,	2155,	1354,	2693
	2920,	2655,	3292,	2591,	1675,	3463
	1553					
Grunkel	2480,	1179,	3510,	2797,	1553,	2829
Grunpy	0209					
H&B	0838,	2031				
Haier	1645,	3273,	0728,	0294,	2242,	0736
	2918,	0906,	2244,	3820,	2271,	
	0294,	0246,	0247			
Halifax	0246,	0247				
Hampton	2706					
Handic	0248,	0324,	1938			
Hanimex	1643					
Hanns.G	1381,	2816,	1643,	1806,	2057,	2847
Hannspree	2244,					
Hanseatic	0067,	0586,	0529,	0549,	0379,	0193
	0391,	0322,	0574,	0312,	0424,	0350
	0664,	0458,	0400,	0691,	0039,	0324
	0247,	0461,	0117,	0407,	0381,	0744
	0838,	0516,	0655,	2031,	1994	
Hantarex	2227,	2497,	0039,	0067,	0586,	0132
	0546,	0268,	2161,	2162,	0895	
Hantor	0067,	0586				
Harsper	0895					
Harwa	1226					
Harwood	0039,	0442,	0067,	0586,	0517	
Hauppauge	0067,	0586				
HB	2383,	1354				
HCM	0039,	0442,	0067,	0586,	0247,	0248
	0448,	0312,	0294,	1226		
Hedzon	0586,	0067				
Hema	0247,	0039				
Hemmermann	0379,	0574				
Hifivox	0139,	0226,	0598,	0228		
Higashi	0246					
Highline	0294,	0067,	0586			
Hikona	0248,	2013				

Hinari	0238, 0067, 0586, 0039, 0248, 0066
	0209, 0193, 0385, 0473, 2037, 0241
	0517, 0265, 0324, 0294, 1938
Hisawa	0312, 0248, 0485, 0640, 1938, 0744
Hisense	1393, 2128, 1344, 2067, 2429, 1769
Hit	0117
Hitachi	1606, 2030, 2706, 3205, 2237, 1802
	1615, 0511, 0608, 0749, 0255, 1179
	0774, 0386, 1067, 0379, 0760, 1514
	1511, 0471, 2157, 1717, 1697, 1255
	0664, 1075, 0503, 0593, 0582, 0373
	2244, 0226, 0228, 0529, 2035, 2037
	0257, 0827, 0073, 0224, 0510, 0473
	0546, 0102, 0067, 0074, 0586, 0139
	0393, 0578, 0208, 1167, 0135, 0066
	0193, 0522, 0389, 0391, 0659, 0907
	0247, 0336, 2309, 0754,
Hitachi Fujian	0138, 0255
Hitsu	0039, 0640, 0485, 0248
HKC	3542
HMV	0117
Höher	0744, 3464, 1586, 0895, 1179
Home Electronics	0636
Horizont	1647, 3054
Hornyphon	0067, 0586, 0042
Hoshai	0248, 0485, 0312
Huanyu	0404, 0246
Hugoson	0920, 1696, 1247, 2225
Humax	1325, 2087, 1569,
HYD	1661, 1406
Hygashi	0247, 0246
Hyper	0039, 0246, 0247, 0277
Hypersonic	0391
Hypson	0067, 0586, 0744, 0745, 1964, 0294
	0247, 0312, 0485, 0268, 1938, 1067
	0698, 1698, 0516
Hyundai	1311, 1498, 2169, 1356, 1929, 1548
	1324, 1724, 1274, 1661, 1182, 0895
	0906, 1636, 0736, 1586, 1504, 1406
	2184, 2326, 2706, 1179
Iberia	0067, 0586
ICE	0294, 0067, 0401, 0039, 0586, 0248
	0247, 0246
Ices	0248, 0246
Icos	0042
Ict	0067, 1167, 0586
Ideal	1586
Iekei	2061
IISonic	1406, 1643
Iiyama	1247, 0920
i-Joy	3825, 2743, 2591, 3186, 2898, 2195
	3542, 3097
Ikasu	1707, 2276
Imperial	0067, 2120, 0193, 0400, 2119, 0104
	0114, 0538, 0586, 0660, 2227, 0441
	0391, 0379, 0448, 0277, 0226, 0461
	0582

Indesit	0267					
Indiana	0067,	0586				
InFocus	1236,	1460,	2229			
Ingelen	0517,	0640,	0744,	0193,	0391	
Ingersoll	0039					
Ingo Devices	2269					
Inno Hit	0039,	1067,	1697,	0102,	0067,	1338
	0586,	2706,	1179,	0248,	0320,	2309
	0247,	0546,	0277,	0132,	0312,	1615
Innovation	0549,	0067,	0586,	0098		
Innowert	0895,	1328				
Inspira	1354,	1586				
Interactive	0067,	0586,	0042,	0117,	0542,	0305
	0357,	0193,	0391,	0400,	0139,	0598
	0441					
Interbuy	0039,	0067,	0294,	0277,	0098,	0542
	0586					
Interfunk	0067,	0586,	0042,	0117,	0542,	0305
	0357,	0193,	0391,	0400,	0139,	0598
	0379,	0277,	0230			
Internal	0067,	0586,	0654,	0529,	0404,	1939
International	0246					
Intervision	0312,	0247,	0485,	0067,	0098,	0401
	0407,	0549,	0478,	0516,	0400,	0424
	0517,	0444,	0248,	0132,	0461,	0193
	0294,	0277,	0684,	0039,	0586	
Ipure	1724,	1406				
Irradio	0039,	0067,	0586,	0248,	0277,	0320
	0401,	0754,	2051,	0744		
Isis	2706,	1179,	1067			
Isukai	0248,	0067,	0586,	0312,	0485	
ITC	0247,	0582,	0350			
ITS	0067,	0401,	0248,	0312,	0294,	0246
	0039,	0586				
ITT	0193,	1724,	2155,	0510,	0379,	0391
	0503,	0578,	0381,	0223,	0376,	0369
	0238,	0616,	0209,	0574,	0640,	1553
	2087,	2383,	2429,	2705,	2706,	1196
	2745,	1179,	3205			
ITT Nokia	0391,	0578,	0193,	0503,	0510,	0379
	0376,	0238,	0209,	0369,	0381,	0616
	0636,	0640,	0661,	0393,	0461	
ITV	0067,	0294,	0586,	0277,	0404	
Jay-tech	3097,	2269				
JDV	2012					
Jean	0066					
JEC	0065					
JGC	1707,	1739				
JMB	0067,	2706,	0529,	0664,	0404,	0586
	0473,	2037,	1938,	2456,	2136	
Jocel	0742					
JQ	2366					
JTC	3097					
Jubilee	0586					
JVC	0683,	1825,	1848,	2706,	1179,	3205
	2148,	3462,	1183,	0636,	1683,	0401
	0761,	0713,	0066,	0220,	0222,	0223

	0248, 0448, 0123, 0680, 2744, 2973
	3904, 3326, 2035,
Kaisui	0248, 0312, 0067, 0586, 0246, 0485
	0247, 0039
Kaon	2383
Kapsch	0193, 0391, 0236, 0289, 0134
Karcher	0067, 0586, 0451, 0400, 0640, 0193
	0312, 0132, 0294, 0744, 1586, 0636
	2012, 2155, 1338
Kathrein	0586, 0067, 0910
Kawa	0401
KB Aristocrat	0193
Kendo	2706, 0067, 0640, 0586, 0193, 0549
	0542, 0400, 0407, 0393, 0458, 0441
	0132, 0265, 0277, 0678, 1615, 1067
	1467, 0516, 2168, 1179, 1167
Kenmark	2667, 2423
Kennedy	0193, 0236, 0582, 0465
Kennex	1067
Kenstar	2120, 2361, 2362,
Keydo	1732
Keymat	1356, 1443, 1923, 2065
Kingsbrook	1067
Kingsley	0246
Kiton	0586, 0067, 0698, 1698
Kneissel	0067, 0415, 0400, 0640, 0441, 0404
	0529, 0586, 0465, 0289, 0322, 0268
	1938
Kobra	1328
Kolster	0067, 0586, 0132, 0379, 0277, 0248
Konka	0067, 0586, 0401, 0744, 0448, 0248
Kontakt	0517
Korpel	0067, 0586
Korting	0117, 0451, 0400, 0350
Kosmos	0067, 0586
Kotron	0442, 0294, 1930
Koyoda	0039
Kraking	0268
Kriesler	0042
Kuba	0379, 0193
Kuba Electronic	0333, 0379, 0193
Küppersbusch	2706, 0067, 1697
Kyoshu	0442, 0448, 0294
Kyoto	0415, 0193, 0246, 0247
L&S Electronic	0895, 0744
LaSAT	0516, 0400
Lava	1504
Lavis	1067, 0067, 0193
Leader	0039
Lecson	0067, 0586
Lemair	0441
Lenco	0039, 2866, 2829, 2185, 1825, 0067
	0193, 0404, 0586, 0134, 0617, 1067
	2013, 1661, 2489, 1817
Lenoir	0039, 1219, 0920
Lentec	1561, 2061
Lesa	0277

Level	2403					
Levis Austria	0067, 0586					
Lexsor	1226, 1537					
Leyco	0294, 0102, 0067, 0586, 0324, 0609					
LG	1870, 2212, 1453, 1693, 0208, 0067					
	1335, 1872, 1798, 0744, 1667, 0636					
	1751, 0586, 0745, 1964, 0728, 0736					
	2087, 1889, 2937, 1179					
Liesenkötter	0067, 0357, 0358, 0042, 0586					
Lifetec	0067, 0698, 1067, 1167, 0549, 2031					
	0404, 0039, 0542, 0685, 0586, 0744					
	0248, 0294, 1698, 0713, 1278					
Linetech	2706, 1179					
Linsar	1615, 2706, 2309, 1697, 1179, 1067					
	3205,					
Lloyd's	0039					
LME	0461					
Lodos	1067, 1179					
Loewe	0542, 0663, 1914, 0820, 1866, 0117					
	0400, 0322, 0546, 0586, 0685					
Logic	2137					
Logik	2516, 3535, 3035, 1895, 1825, 1067					
	2125, 3458, 3462, 0910, 1247, 1615					
	3861, 3910, 1717, 2137, 1675, 2271					
	0067, 0063, 0041, 0401, 0223,					
	3495, 0698, 1698, 2456, 0549					
Logix	3298					
Lowry	2012					
Luker	0067, 0393, 0236, 0193, 0441, 0586					
Luma	0404, 0039, 0289					
Lumatron	1967, 0393, 2053, 0236, 2501, 0067					
	0586, 0193, 0289, 0391, 0247, 0294					
	0103					
Lumenio	0067					
Lux May	0067, 0039, 0586, 0611					
Luxman	0609					
Luxor	0224, 3205, 0267, 0320, 0393, 0510					
	0522, 0379, 0391, 0238, 0386, 0578					
	0193, 0376, 0503, 0209, 1067, 0247					
	0661, 2706, 1697, 1179					
Madison	0067, 0586					
Magnadyne	0117, 0277, 0546, 0132, 0582, 0193					
	0574					
Magnafon	0546, 0132, 0246, 0103					
Magnavox	0067, 0586					
Magnum	0678, 1817, 0744, 0067, 0586, 0745					
	1319, 1196, 1586					
Majestic	2829, 3542					
Mandor	0294					
Manesth	0067, 0586, 0265, 0247, 0294, 0350					
	0065, 0324, 0193, 0393					
Manhattan	0067, 0906, 0586, 1504, 0698, 1067					
	1297, 0193, 1698					
Manta	3357, 1707, 1732					
Maqma	1819, 1822, 1328, 1732, 1739, 1636					
Marantz	0067, 0586, 0442, 1929					

Marca Canaria	3613				
Marelli	0117				
Mark	0067, 0586, 0247, 0246, 0404, 0039				
	0744, 0745				
Marks & Spencer	1877, 2276, 1800, 2703				
Mascom	1586, 0586, 0067, 2155, 1615, 2227				
Mastec	2027				
Master's	0529, 0067				
Masuda	0401				
Matsui	0473, 1179, 1067, 2667, 2037, 1946				
	2516, 0067, 0225, 0586, 0517, 0039				
	0265, 0207, 0041, 0385, 0102, 0063				
	0066, 0241, 0247, 0324, 0401, 0463				
	0393, 0609, 0485, 0193, 0302, 0379				
	0546, 0065, 0461, 0238, 0075, 0221				
	0365, 0744, 0574, 1938, 0659, 1696				
	0910, 2309, 1697, 2706, 0774, 2591				
Matsushita	0680				
Maxim	1196, 2012, 1586				
McMichael	0073				
Medialine	1236, 1994				
Mediator	0067, 0586, 0042				
Medion	0744, 1406, 0838, 2977, 0067, 3495				
	0549, 0698, 0586, 0542, 2269, 1167				
	0728, 0736, 3079, 1938, 1067, 1467				
	1930, 1278, 1698, 0275, 0661, 1251				
	0910, 1319, 1946, 1196, 1586, 1179				
	2031, 1697, 2309, 1771, 2797, 1879				
	2593, 2706, 3545, 3205				
Megas	0640				
MEI	1067, 0067, 0586				
Melectronic	0376, 0067, 0542, 0139, 0373, 0277				
	0135, 0134, 0404, 0039, 0247, 0510				
	0522, 0246, 0441, 0379, 0193, 0317				
	0586, 0654, 0664, 0391, 0221, 0225				
	0098, 0691, 0744, 1682				
Memorex	0039				
Memory	2013				
Memphis	0367, 0102, 0039, 0415				
Mercury	0067, 0039, 0586				
Merritt	0578, 0391, 0193				
Metz	1563, 0776, 0418, 0477, 0397, 0117				
	1179, 0225, 0565, 0584, 0221, 0067				
	0586, 0305, 0698, 1067, 1698, 1667				
Micromaxx	0067, 0586, 0698, 1067, 0660, 0838				
	1698, 1354, 2031, 0744,				
Microspot	1644				
Microstar	0838				
Miia	2898				
Mikomi	1179, 0774, 1615, 1697, 0067				
Minato	0067, 0586				
Minerva	1278, 0517, 0565, 0225, 0100, 0221				
	0584, 0267, 0546, 0138				
Ministry of Sound	1697				
Minoka	0442, 0067, 0586, 0389				
Mirai	1696, 1882, 2102, 1681				

Mirror	1930
Mistral Electronics	0223
Mitsai	1586
Mitsubishi	0138, 0542, 0067, 0117, 0063, 0066 0231, 0267, 0388, 0223, 0565, 0586 0721, 0238, 1964, 1067
Mitsuri General	0193
Mivar	0639, 0322, 0320, 0321, 0400, 0246 0546, 0247
Mogen	2171,
Monaco	0039
Moree	0067
Morgan's	0067, 0586
mp man	2480, 3326
MTC	0400, 0379, 0542, 0193, 0391, 0478
MTEC	0302
MTlogic	0744, 1338, 2080, 2134
Multibroadcast	0223
Multimat	0462
Multistandard	0132, 0462
Multitec	0067, 0586, 0516, 0698, 1067, 1586 1698, 2012
Multitech	0379, 0039, 0393, 0516, 0067, 0400 0586, 0247, 0246, 0277, 0132, 0294 0582
Murphy	0134, 2035, 1879, 0246, 0473, 2703 2276, 0102, 0193, 2037, 3205, 2706 0231, 0381, 1697, 1179, 2136
Musikland	0067, 0248, 0277, 0586
Mx Onda	1717, 2013, 1675, 2171,
MyCom	1406, 0208
Myryad	0586, 0067
Mystery	2271, 3326, 3077
NAD	2452, 0895
Naiko	0067, 2012, 0636, 0586
Nakimura	0404, 0067, 0586
Naonis	0393, 0193
Narita	2012
National	0256
Naxoo	3545
NEC	0200, 0275, 1734, 1200, 0066, 0350 0485, 0039, 0404, 0247, 0067, 0586 0041, 0734, 0267, 0529, 0683, 0691 1827, 2229, 3287
Neckermann	0067, 0221, 0400, 1535, 1040, 0230 0584, 0586, 0582, 0193, 0357, 0448 0379, 0117, 0277, 0247, 0441, 0350 0393, 0542
NEI	0067, 0586, 0367, 0461, 0401, 0193 1067
NEO	0784, 1354, 3354
Neon	1762, 2276, 1800, 2088, 2703, 0783
Neovia	1236, 0895, 1994, 1403, 1401, 0906 1406
Nesco	0277, 0209, 0444, 1938
Nesx	1762
Netway	2139

Network	0367				
Neufunk	0067,	0039,	0586,	0640,	0248, 0312 0744
Nevir	2829,	2706,	2504,	3205	
New Tech	0067,	0039,	0586,	0373,	0247, 0478
New World	0248				
Nicamagic	0246				
Nikkai	0102,	1707,	0248,	0067,	0586, 0247 0294, 0065, 0367, 0246, 0039, 0066 1697
Nikkei	0744,	2199,	2202,	2227,	1615, 3820 2706, 2309, 1697
Nishi	0512				
Nissan	2366				
Nobliko	0132,	0100,	0246		
Nogamatic	0139,	0226,	0598		
Nokia	0391,	0193,	0510,	0379,	0578, 0522 0389, 0503, 0381, 0369, 0238, 0404 0616, 0661, 0636, 0376, 0209, 0350 0640, 0139
Nordic	0247				
Nordmende	0590,	0139,	2361,	3054,	2120, 0317 2362, 2031, 0226, 0373, 0228, 0598 0225, 0067, 0586, 0365, 0193, 0501 1278, 0744, 1319, 1443, 0473, 2037 1615, 1697, 1179, 1338, 0655, 2706
Norfolk	0193				
Normerel	0067,	0586			
Nortek	0698				
Northern Star	1236				
Novak	0042,	0067,	0586		
Novatronic	0067,	0135,	0404,	0586	
Novex	1553				
Novita	1615				
NPG	3464				
Nurnberg	0193,	0391			
O.K.Line	0701,	1067,	1354,	1586	
Oceanic	0193,	0391,	0324,	0238,	0593, 0503 0578, 0510, 2031
Odeon	0294,	1825			
Odys	1825,	2829,	2958,	2269,	2195, 3859 3542, 3495, 2271, 3273, 3545
OK.	3464,	2706,	3097,	3462,	2269, 3077
Okano	0400,	0067,	0586,	0294,	0102, 0039
OKI	1067,	2155,	2230,	1697,	1615, 3464 3495, 2706, 1338, 2977, 1179
Olidata	1406				
Omega	0294				
Onei	1697				
Onimax	0744				
Onn	2196,	2275,	1739,	3054,	2194, 1586 1179, 2155, 0586, 1697, 1800, 2309
Onwa	0401,	0248,	0463,	0611,	0132, 0461
Onyx	1739,	1800			
Opera	1338,	0067,	0586,	0744,	2168, 1615
Optoma	1784,	2778,	2826		
Orava	0582,	1067,	1179,		

Orbit	0067, 0586
Orbitech	2452
Orion	1965, 2037, 2061, 2271, 2035, 0067 0473, 0385, 0744, 0265, 2138, 0586 0685, 0324, 0207, 0350, 0041, 0039 0351, 0241, 0132, 0294, 0442, 0546 0574, 1946, 1938, 0063, 0910, 1226 2030, 2031, 1984, 1067, 1945, 3829 3903, 2706
Orline	0067, 0248, 0586
Ormond	0415, 0698, 1067, 0067, 0586, 1698
Orsowe	0546
Osaki	0102, 0248, 0247, 0294, 0523, 0067 0442, 0302, 0404, 0241, 0385, 0586
Osio	0067, 0586, 0320
Oso	0248
Osume	0187, 0102, 0066, 0248, 0067, 0586
OTIC	1717, 1675, 2013
Otto Versand	1535, 1040, 0066, 0123, 0542, 0067 0586, 0565, 0225, 0574, 0379, 0584 0221, 0391, 0265, 0139, 0324, 0256 0277, 0333, 0350, 0247, 0039, 0312 0373, 0458, 0461, 0546, 0549, 0582
OVP	1610
Pace	1938
Pacific	0067, 1946, 2090, 0586, 1167, 1267 1938, 0744, 1067, 0473, 1354, 2037
Packard Bell	1344, 1504
Pael	0246
Palladium	0400, 0067, 0685, 0441, 0660, 0744 1167, 0221, 1535, 1040, 0230, 0448 0584, 0586, 0379, 0277, 0357, 0117 0582, 0193, 0549, 0247, 0393, 2012
Panache	1615
Panama	0039, 0247, 0294, 0246, 0067, 0586 0277
Panasonic	1666, 0680, 1680, 0256, 1340, 0304 1240, 0244, 0391, 0883, 0267, 0880 0397, 0546, 0067, 0586, 0193, 0578 0381, 0138, 2294, 3855, 2706
Panavision	0067, 0441, 0586
Papouw	0067, 0586
Pathe Cinema	0193, 0268, 0246, 0350, 0322, 0379 0461, 0582, 0400
Pathe Marconi	0139, 0226, 0228, 0267, 0598
Pausa	0039
PEAQ	3205, 3077, 2706
Perdio	0102, 0350, 0193, 0067, 0246, 0312 0586
Perfekt	0067, 0586
Philco	0117, 0114, 0104, 0448, 0277, 0582 0193, 0400, 0067, 0586, 0549
Philex	0231, 0193, 0381
Philharmonic	0247
Philips	0586, 1774, 1536, 0067, 0669, 2045 1613, 1525, 1897, 0635, 1917, 1485 0802, 2830, 0043, 0042, 0584, 0073

	0117, 0223, 0453, 0373, 0404, 0039
	0230, 0391, 2798, 2710, 3394, 3820
	2244, 3644, 3221, 3708
Phocus	1319, 1338, 0744, 1682
Phoenix	0067, 0586, 0400, 0516, 0193, 0117
	0102, 0246, 0350, 0415, 0582
Phonola	0067, 0586, 0042, 0043, 0117, 0223
	0246
Phonotrend	2185
Pioneer	1290, 0790, 1487, 0196, 0709, 0067
	0586, 0453, 0458, 0373, 0391, 0139
	0193, 0317, 0516, 0542, 2488
Pionier	0400, 0516
Plantron	0067, 0586, 0294, 0039
Play	1297
Playsonic	0744, 0067, 0247, 0369, 0745, 1682
Polar	0067
Polaroid	1553, 3619, 2706, 3205, 1697, 1750
	1675, 3326, 1717, 1771, 2155
Policom	0598, 0132, 0139, 0226, 0228, 0236
	0267, 0268, 0305, 0391, 0193, 0100
	0104, 0114, 0117, 0565
Poppy	0039
Portland	0404, 0654, 1939
Powerpoint	0517, 0067, 0586, 0728, 0736, 1800
	2171
Pragma Digital	0838
Prandoni-Prince	0277, 0546, 0391, 0393
Precision	0247
Premier	0921
Prestigio	1930
Prima	0039, 0294, 0333, 0098, 0442, 1537
	1226
Princeton	1067
Prinz	0102, 0574, 0379, 0391, 0224
Pro Vision	0529, 0067, 0586, 1067, 0744, 1354
	1561
Profex	0039, 0193, 0461, 0391, 0393
Profi	0039
Profilo	1586
Profitronic	0067, 0586, 0132
ProLine	0664, 1757, 2667, 1575, 1067, 0655
	2165, 0067, 0586, 0660, 0441, 0042
	0351, 0102, 0651, 1406, 2134, 2253
	2706, 2423, 1179, 1615, 1697
Prosonic	0067, 2061, 1769, 0586, 1895, 0400
	2115, 0404, 0910, 0401, 0698, 1406
	0744, 2169, 2171, 0481, 0246, 2758
	2706, 0244, 1923, 2031, 0609, 1354
	0247, 1698, 1800, 1762, 1344, 2120
	2136, 1739, 2275, 0636, 1179, 1537
	3495, 3510, 2227, 2299, 2480, 2293
	3611, 2130, 1817, 2456, 2155, 1575
	1879, 0745, 1226, 1874, 2080, 2051
	2693, 0906, 1553, 2511, 2309, 2241
Protech	0067, 0586, 0247, 0039, 0277, 0379
	0132, 0294, 0461, 0448, 0367, 0698

	0312, 0582, 0193, 0516, 1067, 1698
Protek	2366, 1661
Proview	1717, 1675
Proxima	0765
Pye	0067, 0586, 0042, 0043, 0117, 0584 0404, 0379, 0442
Pymi	0039
Q.Bell	2591, 3357
Q.Media	2866, 3524, 3645, 3545, 3655, 2120
	2829
QONIX	3097, 1664, 2195
Quadral	0248
Quadro	0783, 1356, 0586, 0067, 0851, 1179
	1697
Quartek	1636
Quasar	0277, 0895, 0039
Quelle	0067, 1535, 1040, 0041, 0139, 0542 0565, 0574, 0379, 0584, 0221, 0391 0066, 0247, 0277, 0104, 0357, 0114 0358, 0336, 0100, 0134, 0135, 0698 0586, 0187, 0225, 0230, 0294, 0320 0176, 1067, 0324, 0376, 0451, 0582 0039, 1698
Questa	0066
Radialva	0139, 0248, 0461, 0193, 0067, 0586 0317, 0367
Radiola	0067, 0586, 0042, 0247
Radiomarelli	0117, 0231, 0546, 0277, 0067, 0586
Radionette	0744
RadioShack	0067, 0586
Radiotone	0039, 0067, 0586, 0458, 0400, 0609 0448, 0442, 0678, 0698, 0294, 1067 1698
Rafena	0327
Rank	0100
Rank Arena	0066, 0187
RBM	0100, 0119
Recor	0067, 0586
Rectiligne	0067, 0586
Red	2271
Red Star	0067, 1586, 0586
Rediffusion	0231, 0391, 0381, 0578, 0066, 0376
Reflex	0067, 0586, 1067, 0698, 1698
RefleXion	3263
Relisys	1769, 0907, 1771, 0895, 0906, 1236 1328, 1406, 1615, 2244, 1675
Reoc	0744, 0654, 0664, 1939, 2227
Revox	0067, 0838, 0586, 0400
Rex	0236, 0393, 0441, 0277, 0193, 0289 0294
RFT	0327, 0117, 0322, 0400, 0458, 0102 0294, 0067, 0586, 0516
Ricoh	0067, 0586
R-Line	0067, 0586, 0193
Roadstar	1067, 0745, 0039, 0448, 0067, 0586

	0744, 0698, 0248, 0294, 0312, 1946
	1698, 1219, 1930, 1585, 1356, 2171
	1707
Robotron	0117
Rolsen	1401, 0067, 0586, 2128, 2067, 2031
Rover	0907
Rowa	0294, 0247, 0039, 0246, 0617, 0067
	0586
	0478
Roxy	
Royal Lux	0451, 0400, 0442, 0365
Rukopir	0586, 0067
Saba	0655, 1196, 0139, 0590, 0373, 0317
	0117, 0193, 0546, 0391, 0528, 0226
	0228, 0365, 0598, 0578, 0501, 0680
	0744, 1618, 2706, 1615, 3205
Sacccs	0268
Saga	2227
Sagem	0640, 0485, 0312, 0860, 0648
Saisho	0265, 0546, 0207, 0039, 0041, 0063
	0247, 0461, 0193, 0294, 0241, 0574
Saivod	2012, 0067, 0586, 1179, 1586, 0698
	0742, 1067, 1697, 1698, 3510
Sakai	0193
Salora	0320, 0224, 0379, 0193, 0386, 0389
	0391, 0546, 0393, 0578, 0369, 0238
	0582, 0510, 0651, 1267, 0661, 1196
	1586, 1401, 2184, 2155, 2227, 2031
	2706
Salsa	0365
Sambers	0546, 0132
Samsung	2081, 0842, 0648, 0617, 1488, 1649
	0586, 1279, 1342, 0674, 1265, 0039
	0067, 0247, 0478, 0512, 0400, 0090
	0796, 0844, 1937, 0102, 0294, 0712
	0246, 0320, 0549, 0193, 3194, 0748
	0208,
Sandra	0246, 0247
Sandstrøm	2429, 2227, 3462,
Sanela	0268
Sansui	0067, 1712, 0586, 3825, 0401, 1965
	2862
Santon	0039
Sanyo	0238, 1238, 0187, 0322, 0066, 0041
	0400, 0369, 0102, 0246, 3126, 0247
	0134, 0075, 0585, 0176, 0039, 0574
	0193, 0067, 0327, 0586, 0516, 0765
	0200, 0734, 1679, 1067, 1697, 1179
	1615, 2309, 2706
Save	0067, 0586
Saville	1938
SBR	0067, 0586, 0042, 0223, 0043, 0073
ScanSonic	1817
Schaub Lorenz	0578, 2199, 2271, 2202, 0744, 0391
	0379, 2227, 0636, 0516, 0404, 1354
	1393, 1401, 2130, 1697, 2155, 0906
	1338, 2230, 2706, 1179, 3298, 2319

	1615, 2309				
Schneider	1167, 2706, 2866, 0067, 0586, 1615				
	0549, 0042, 0333, 0574, 0379, 0424				
	0382, 0289, 0373, 0247, 0277, 0401				
	0391, 0248, 0698, 1067, 0193, 0678				
	0744, 0043, 0654, 1939, 1938, 1698				
	2012, 1946, 0100, 1647, 1504, 1354				
	1267, 3054				
Schöntech	1067				
Scotland	0193				
Scott	1219, 1553, 2013, 3613, 1825				
Sears	0176				
Seaway	0664				
Seeltech	3298, 3097				
Seelver	0586, 1067, 0067				
SEG	1067, 2269, 1739, 0067, 1179, 3859				
	3464, 0586, 3970, 1467, 0698, 0247				
	0517, 0039, 0379, 0193, 0294, 0327				
	0664, 0066, 0132, 0277, 0444, 0246				
	0582, 0248, 1939, 0654, 1698, 2168				
	2155, 2195, 2480, 2703, 1553, 1615				
SEI	0117, 0132, 1535, 1040, 0582, 0193				
	0546, 0574, 0379, 0324, 0236, 0067				
	0586, 0207				
Sei-Sinudyne	0132, 0236, 0324, 0546, 1535, 1040				
	0582, 0574, 0067, 0586, 0117				
Seitech	1247, 1354,				
Selecline	3326				
Seleco	0236, 0393, 0289, 0193, 0441, 0401				
	0066, 0294, 0376, 0465, 0660				
Sencor	0744, 2505, 3097, 2269, 2227				
Sencora	0039				
Sense	1877, 1879				
Sentra	0065, 0248, 0039, 0379				
Serie Dorada	0208				
Serino	0640, 0485, 0246, 0123, 1123				
Sharp	1423, 2706, 0123, 1223, 1616, 1123				
	2244, 0187, 0066, 1849, 3820, 0324				
	0286, 0223, 0546, 0230, 1179, 3381				
	1965, 3826, 3205,				
Shinelco	2134, 2271,				
Shintoshi	0067, 0586				
Shivaki	0067, 0586, 0473, 2037, 0481, 0404				
	0208				
Shorai	0324, 0209				
Siarem	0582, 0193, 0117, 0132, 0546				
Siemens	0221, 0565, 0584, 0230, 0225, 0357				
	0358, 0187, 0176, 0067, 0586, 0391				
Siera	0067, 0586, 0042, 0617				
Siesta	0400				
Silva	0067, 0586, 0246, 0391, 0678				
Silva Schneider	0783, 1586, 2196, 0678, 2155, 2227				
	3097, 2363				
Silver	0066, 0391, 0209, 0745, 0193				
SilverCrest	1067, 0067, 0586, 2706				
Simz	2171,				

Singer	0039, 0117, 0067, 0586, 0132, 0277 0465, 0365, 0193
Sinudyne	1354, 2706, 1697, 0207, 0117, 0265 0132, 0324, 0582, 0193, 0391, 0546 0574, 0379, 1535, 1040, 0236, 0067 0586, 1938, 0636
Skantic	0386
Sky Media	0910, 1644, 0208, 1643, 1636, 1645 1406, 1805, 1739, 0691, 0895
Skymaster	0135
Sliding	0895, 0910, 1354,
SLX	0698, 1698
Smaragd	0517
SmartVision	1873
Sodiff	2366
Soemtron	0895, 1328
Sogera	0350
Sogo	1406, 2080, 3097, 3542
Solavox	0391, 0102, 0193, 0578, 0381, 0067 0586
Sonawa	0248
Sonber	0132
Soniko	0067, 0586
Sonitron	0238, 0400, 0369, 0247
Sonix	1762
Sonneclair	0067, 0586
Sonoko	0067, 0586, 0039, 0294, 0312, 0247
Sonolor	0238, 0193, 1535, 1040, 0578, 0391 0312
Sontec	0067, 0586, 0400, 0324, 0039
Sontech	2013
Sony	1855, 2808, 1535, 1681, 1581, 1655 1040, 0041, 0383, 0066, 0132, 0187 3391, 2615
Sound & Vision	0132, 0248, 0404, 0067, 0586
Soundwave	0067, 2276, 2703, 0586, 0350, 0448 0745, 1877
SOVOS	2269
Soyo	1739
Ssangyong	0039
Standard	0067, 2271, 2120, 0586, 1712, 1067 0248, 0039, 0247, 0350, 0404, 1739 2829
Starion	1067
Starlite	0039, 0582, 0193, 0067, 0586, 0294 0442
Starmedia	2139
Stenway	0312, 0248
Stern	0236, 0289, 0193, 0393, 0294, 0441 0465
Stevison	2012, 1586
Strato	0067, 0586, 0294, 0039, 1817
Strong	1179, 1067, 0067, 0586
Stylandia	0247
Sungoo	1278, 2067
Sunic Line	0067, 0586
Sunkai	0324, 0385, 0351, 0485, 0248, 0265

	0640, 0067, 0586, 0517, 0895, 1553
Sunny	0067, 1647
Sunstar	0401, 0067, 0586, 0039, 0609, 0294
Sunstech	2031, 2480, 3273, 3545, 1994, 2706 2271,
Sunwood	0067, 0586, 0039
Super	1219
Superla	0546, 0246, 0247
SuperTech	0039, 0067, 0586, 0246, 0248
Superton	0461
Supra	0404, 0039
Supratech	2241, 2238, 3097,
Susumu	0365, 0248, 0317
Sutron	0039
Swedx	1636
Sweex	2504, 2591
Swissline	0277
Swisstec	1805, 1739, 1644, 1636, 1643, 1645 0910, 1406, 0895, 1806, 1879, 2089 2134
Sydney	0246, 0247
Sysline	0067, 0586
Sytong	0246
T+A	0477
Tactus	0302
Tandberg	0397, 0441, 0139, 0367, 0226, 0391 0193
Tandy	0248, 0102, 0247, 0277, 0123, 0193 0444
Targa	1401, 1297, 0648, 2275, 3552
Tashiko	0066, 0073, 0247, 0176, 0200, 0246 0389, 0193, 0393
Tatung	1750, 0651, 0067, 1278, 1586, 0586 0102, 0546, 0247, 0302, 0279, 0041 0274, 0659, 0079, 0063, 1938, 1401 1749, 1354, 2445, 3054, 1946
Tauras	3097, 2227, 3054
TCL	3077, 2705,
TCM	0744, 1319, 0838, 2031, 1338
Teac	1675, 2198, 3035
TEC	0247, 0039, 0277, 0501, 0365, 0367 0289, 0582, 0067, 0586, 0391, 0193
Tech Line	1615, 0067, 0586, 0698, 1467, 1698 1179
Tech Lux	1219
Technema	0350
Technica	2012, 0651
Technical	1697, 2706
Technika	2136, 2271, 2456, 1895, 2706, 2198 2089, 1879, 2242, 1697, 2013, 1615 2155, 2227, 3035, 3495, 2012, 3097
TechniSat	0685, 3205, 0327, 0067, 0586, 0193 1297, 2185, 2452
Technisson	0744, 1319, 1682
Techno	1615, 1067
Technol Ace	0209

Technosonic	0655, 2271, 2012, 0529, 0586, 1923 1354, 0910, 0067, 1356, 0744
Technotrend	1732, 2185, 1561
Techvision	1739, 2271, 1561
Techwood	1179, 2706, 1067, 1697, 2309
Teckton	1406
Tecnimagen	0586
Teco	2139, 1553, 2210
Tecsonic	2747
Tedelex	0247, 0636, 0067, 0039, 0238, 0617 0586, 0461
Teiron	0039
TELE System	0906, 1707, 2155, 3273, 1615, 1067 0067, 2271, 2693, 1697, 2706, 3464
Teleavia	0139, 0317, 0226, 0598, 0373
Telecor	0067, 0586, 0193, 0248, 0247, 0289 0424
Telefunken	0655, 1697, 2269, 2829, 0838, 0590 0104, 0139, 0373, 0528, 0292, 0501 0317, 0114, 0131, 0365, 0336, 0103 0226, 0067, 0586, 0516, 0598, 0744 1586, 0376, 0851, 1615, 1618, 1179 2706, 3205,
Telefusion	0067, 0586
Telegazi	0067, 0193, 0289, 0248, 0294, 0586
Telemeister	0350, 0067, 0586
Telesonic	0067, 0586
Telestar	0067, 0586, 2120, 2348, 0609, 1879 0442
Teletech	0067, 0586, 0698, 0039, 0277, 0367 0444, 1067, 1698
Teleton	0247, 0305, 0236, 0193, 0379, 0289 0066, 0393
Televideon	0350, 0582, 0193, 0246
Television	0067, 0586
Telexa	0132
Telstar	1732
Temco	0324
Tennessee	0067, 0586
Tensai	0134, 0248, 0067, 0586, 0247, 0324 0350, 0039, 0135, 0404, 0401, 0407 0277, 0745, 0193, 1067
Tenson	0350, 0039
Terra	2918
Terris	2271
Tesco	2456
Tesla	1067, 0067, 0698, 0744, 1682, 0745 1167, 0660, 0401, 0726, 0549, 0783 0586, 0268, 0640
Tevion	0549, 1278, 1328, 1675, 0586, 0678 1586, 1817, 2271, 0698, 0838, 0895 2130, 1167, 1717, 1067, 1698, 2403 1319, 1615, 3298, 2053, 0744, 1771 3495, 2120, 2155, 0067, 2227, 2489 1553
Texet	0247, 0404, 0039, 0246, 0248
Thes	2066, 2061, 1879, 2977,

Thomas	1934				
Thomson	0655,	0590,	0373,	0317,	0139, 3077
	0501,	0365,	0226,	1618,	0228, 0267
	0067,	0586,	0598,	0350,	0379, 0246
	0582,	3329,	2705,	2745,	
Thorn	0138,	0223,	0139,	0103,	0255, 0373
	0391,	0220,	0268,	1535,	1040, 0222
	0104,	0114,	0565,	0529,	0067, 0102
	0586,	0134,	0041,	0042,	0365, 0542
	0043,	0063,	0389,	0066,	0073, 0302
	0404,	0075,	0100,	0065,	0131, 0583
	0386				
Thorn-Ferguson	0134,	0220,	0222,	0223,	0365, 0065
Time	1822,	1732,	2027		
Tiny	1226				
Tiny Digital	0690				
Tokai	0102,	2862,	0067,	0586,	0367, 0698
	0478,	0193,	0247,	0404,	0039, 1067
	0582,	1698			
Tokaido	1067				
Tokyo	0246,	0065,	0478,	0333	
Tomashi	0312,	0248			
Topline	1067,	0698			
Toshiba	1538,	2706,	0538,	2762,	0065, 0583
	1319,	1697,	2805,	3272,	0744, 0273
	0748,	1965,	0132,	0271,	1612, 1453
	1734,	0247,	0225,	0221,	0648, 1946
	1938,	0039,	0067,	1586,	0680, 1067
	2628,	1179,	1682,	0770,	2816, 0119
	0100				
Tosumi	2012,	1800			
Towada	0379,	0132,	0247,	0582	
Toyoda	0039				
Trakton	0294				
TRANS-continents	0698,	1067,	0895,	0586,	0067, 0651
	1698,	0516,	0247		
Transonic	1707				
Transtec	0246				
Triad	0067,	0586,	0248,	0039	
Trical	0187				
Trident	0546,	0247			
Trio	1717,	1675			
Tristar	0294,	0248,	0223		
Triumph	0207,	0546,	0376,	0586,	0067, 0273
Tsoschi	0312				
Tucson	2706				
TVE	2269				
TVTEXT 95	0586				
Uher	0067,	0586,	0236,	0350,	0333, 0404
	0448,	0516,	0400,	0289,	0510
Ultra	0222				
Ultravox	0117,	0132,	0404,	0277,	0246, 0582
	0193,	0067,	0586,	0381,	1615
UMC	1636,	2456,	1805,	1739,	1644, 1879
	2089,	2136,	2195,	2198,	2137, 3495
Unic Line	0067,	0586,	0503,	0485,	0379

United	0744, 2013, 2977, 0067, 2829, 0745
	0586, 2866, 2511, 1946, 1938, 3272
	2271, 1067, 0617, 3542, 2012, 2230
	1879, 1682, 2171, 2693, 3326, 3464
	1800, 0538, 3263, 1553, 3510, 2155
	3545, 1179
Unitek	1739
Universal	0684, 0067, 0586
Universum	0838, 1067, 0067, 1179, 0376, 0698
	0135, 0510, 0225, 0503, 1467, 0134
	0565, 0391, 0041, 0542, 0277, 0522
	0400, 0230, 0448, 0176, 0324, 0066
	0187, 0100, 0582, 0193, 0294, 0586
	0451, 0441, 0320, 0104, 0336, 0357
	0358, 1535, 1040, 0574, 0379, 0247
	0139, 0367, 0207, 0661, 0584, 0039
	0114, 1267, 0200, 1698, 0648, 2204
	1758
Univox	0067, 0586, 0367, 0117, 0193, 0268
Utax	0193
V2M	0684
V7 Videoseven	2061, 0208, 0910, 1406, 1247, 1696
	1297, 0648, 1681, 1535, 3389
Vanguard	0067, 0586
VD-Tech	2829, 3097
Vector	2066
Venturer	1757, 1575, 1895, 3035
Venus	1356
Vestel	1067, 2706, 1179, 1615, 1697, 0067
	0698, 0582, 0193, 0247, 0586, 1698
Vexa	0039, 0067, 0586
Vibrant	0302
Videocon	2361, 2362, 3326
Videologic	0248, 0246
Videologique	0246, 0248, 0247
Videosat	0277
VideoSystem	0067, 0586
Videotechnic	0246, 0350, 0247, 0404
Videoton	0386, 0193, 0461
Vidikron	0132, 0765
Viewpia	0906, 2591,
ViewSonic	1360, 1572, 1618, 2139, 2141
Viper	0367
Visiola	0246
Vision	0067, 0586, 0350, 0247
VisionPlus	2456, 2136
Visorex	0462
Vistar	0236, 0391
Vistron	1393, 1877
Visual Innovations	2136
Vivax	1873, 1356, 1338, 1647, 1732, 0067
	1739
Vortec	0067, 0586
Voxson	0117, 0067, 0586, 0393, 0448, 0193
	0208, 2227, 2210, 0684
VU	2429
Walker	1697, 1179, 2309, 2383, 2706, 0067

	1067, 1615, 2168
Waltham	0247, 0386, 0448, 0317, 0415, 0067 0586, 0698, 0139, 1067, 0461, 1698 0193, 0473, 2037
Wards	0209
Watson	1067, 1278, 0350, 0586, 0067, 0193 0039, 0698, 0248, 0609, 0549, 0424 0684, 1938, 1467, 1698, 1406, 0357
Watt Radio	0132, 0574, 0379, 0582, 0193, 0246 0516, 0458
Wega	0067, 0586, 0066, 0117
Wegavox	0039, 0067, 0586, 1179, 1697
Welltech	0744, 1682
Weltblick	0067, 0586, 0350, 0247
Weltstar	1067
Weston	0067, 0586
Westwood	1615
Wharfedale	2013, 1697, 1354, 2242, 0067, 1067 0744, 0549, 1267, 0586, 1586, 0701
Whip	2017
White Westinghouse	0350, 0246, 0067, 0586, 0367, 0654 1939
Wilson	0586
Windsor	0698, 1067, 1698, 3205
Windstar	0312, 0367
Windy Sam	0586
Wintel	1707
World-of-Vision	0910, 0920, 0895, 1319, 1328, 0907 1636, 1247, 1762
Woxter	1561
XDome	0538
Xenius	0664, 1697, 2706, 1615
Xiron	2011, 2013, 1067
Xomax	1800, 3545, 3097
Xoro	1226, 1247, 3224, 1537, 1819, 1354 2178,
Xrypton	0067, 0586
Yakumo	1643
Yamaha	0680, 0827, 1606
Yamishi	0312, 0485, 0248, 0067, 0586, 0247
Yokan	0067, 0586
Yoko	0247, 0067, 0586, 0248, 0294, 0039 0461, 0451, 0400, 0369, 0246, 0277
Yorx	0248
Ytawai	1561
YU-MA-TU	0067
Yüsmart	1643
Zaapa	1219
Zanela	0268
Zanusssi	0236, 0393, 0247
Zenor	0369
Zephir	3825
Zepto	1615
ZX	1938